

External Antenna for Wireless Wiring Centre

Model: **CFA**



Quick Guide



March 2020
V004

COSMO GmbH
Brandstücken 31
22549 Hamburg
info@cosmo-info.de
www.cosmo-info.de

INTRODUCTION

The **CFA** External Antenna improves the performance of compatible devices to either overcome radio shadows or extend the range.

It can be connected to the **CFKL8** wiring centre.

PRODUCT COMPLIANCE

This product complies with the essential requirements and other relevant provisions of Directives:
EMC 2014/30/EU, LVD 2014/35/EU, RED 2014/53/EU and RoHS 2011/65/EU.

(9) 2405-2480MHz; <14dBm

SAFETY INFORMATION

Use in accordance with the regulations. Indoor use only. Keep your device completely dry. Disconnect your device before cleaning it with a dry cloth. This accessory must be fitted by a competent person, and installation must comply with the guidance, standards and regulations applicable to the city, country or state where the product is installed. Failure to comply with the relevant standards could lead to prosecution.

TECHNICAL SPECIFICATION

Connections	RF: Reverse Polarity SMA-K plug
Mechanical	Magnetic Mount
Cable length	1 Meter
Weight	37 g
Dimensions [mm]	131 x 29
Operating Temperature	5 - 60 °C
Storage Temperature	-20 - 60 °C

CONNECTION WITH CFKL8 WIRING CENTRE



The external antenna connector is located underneath the wiring centre under zones 7 and 8.



After connecting an additional antenna, place the jumper in the EXT position.



Jumper position change must be refreshed in the memory by pressing the Reset button (short press).



